



SpillTech

Smart Spill Solutions™

Installing an “Instaberm” Style Containment Berm

Instructions:

Step 1: Unfold the berm

Step 2: Pull all 4 sidewalls of the berm outward so that they are standing upright.

Step 3: Straighten the top angles of the inner brackets. The walls will move further outward as the berm is filled.

Note: If the berm has been stored for a long period of time, the brackets may need to be flexed

If using as a drive-in berm, stand the brackets on 3 sides, leaving the wall of the 4th side down. The 4th wall should be a “short side” wall. Drive vehicle into the berm (it is recommended that you use Track Guards for this movement). Once inside, push the 4th wall outward to a standing position.

If you are using a **Ground Cover**, it should be placed between the ground and the berm. It is best to lay the Ground Cover out flat before unfolding the berm.

Track Guards should be placed inside the berm after the 3 initial walls have been set up. Track Guards should run parallel to the “long side” of the berm.

